SLAT

BYD Atto 3

Before driving

Unlock the vehicle

The BYD Atto 3 comes with a similar key to any regular vehicle and can be locked and unlocked using the buttons on the key. You can also use your finger by pressing on the handle to unlock the car, but you'll need to have the key on you to activate this feature.

Start the vehicle

Once inside, place the key in a safe spot, touch the brake pedal and press the Start/Stop button next to the steering wheel to start the vehicle's engine.

Driving modes

To choose your driving mode (Drive or Reverse) use the clearly labelled gear shifter in the centre console in front of the cup holders. You'll soon find the Atto 3 is fairly similar to most new cars and easy to navigate the options and basic driving features.

The electronic parking brake sits below your Start/Stop button.

Vehicle infotainment and navigation

Vehicle infotainment and navigation can be controlled via the main screen in the middle of the dashboard. This operates like a smartphone where you'll also find other personalisation options, including climate control, Bluetooth and more.

Window and door controls can be found under the vehicle's door handle which is above the door speaker.

While driving

Important driving information can be found on the display behind your steering wheel. This includes your speed, charge level and range.

Performance

The Atto 3 should give you upwards of 450km of range depending how it's driven and the use of air conditioning.

Driving the car can feel a bit different from a regular petrol-powered car, firstly by the lack of engine noise and secondly by the slightly more abrupt braking when taking your foot off the accelerator.



More information on your SIXT EV, instructional videos and available charging stations can be found using the QR code.



BYD Atto 3

Charging

Your Atto 3 is simple to charge. Remember, you'll need to have your vehicle unlocked to open the charge port located at the front of the vehicle.

1

Open the charge port by tapping on the charge port cover above the front wheel fender on the driver's side. 2

Open the dust caps inside the port and make sure the connection is correct before trying to plug it in. 3

Firmly plug the charge connector into the charge port to initiate charging.

4

The instrument screen behind the steering wheel will show that it's charging along with the time remaining until it's full. 5

If you lock your car the charger cannot be removed and will stay charging until you unlock the car and remove the charger.

6

The display will show when charging is complete, and you can interrupt charging at any time.

To unplug the charger:

1

Press the charger's clearly visible connector button.

2

Take out the charger and return it to its holder.

3

Make sure the vehicle's charge port cover is closed before resuming driving.



Free charging with Chargefox

All SIXT Australia customers get free electric vehicle charging with Chargefox. Your vehicle will come with a Chargefox card or fob, which can only be used at Chargefox locations.

The card or fob is already linked to a SIXT Chargefox account, so all you need to do is follow the instructions on the charger, and tap/swipe at the location and plug in the charger. A full list of charge locations can be found on the Chargefox app which is free to download from the App Store or Google Play.